

實戰一

```
1 import numpy as np
2 import cv2
3 from matplotlib import pyplot as plt
4 from google.colab import drive
5 from google.colab.patches import cv2_imshow
6 drive.mount('/content/drive')
7 img = cv2.imread("/content/drive/My Drive/Colab Notebooks/image_processing/Lenna.bmp")
8 print(img.shape)
```

Drive already mounted at /content/drive; to attempt to forcibly remount, call drive.mount("/content/drive", force_remount=True).
(512, 512, 3)

掛載雲端硬碟，並載入圖片

```
1 nr, nc = img.shape[:2]
2 x0 = nr // 2
3 y0 = nc // 2
4 sigma = 200
5 illumination = np.zeros([nr, nc], dtype = 'float32')
6 print(illumination.shape)
7 for x in range(nr):
8     for y in range(nc):
9         illumination[x, y] = np.exp(-((x - x0)**2 + (y - y0)**2) / (2 * sigma * sigma))
```


(512, 512)

對圖片進行處理

```
1 new_img = img.copy()
2 for x in range(nr):
3     for y in range(nc):
4         for k in range(3):
5             val = round(illumination[x, y] * img[x, y, k])
6             new_img[x, y, k] = np.uint8(val)
7 images = [img, illumination, new_img]
8 titles = ['Original', 'Gaussian', 'Image Fromation']
9 plt.figure(figsize = (15, 15))
10
11 for i in range(3):
12     plt.subplot(1, 3, i + 1), plt.imshow(images[i], 'gray')
13     plt.title(titles[i])
14
15 plt.tight_layout()
16 plt.show()
```

顯示三種圖片

執行結果：



實戰二

```
1 import numpy as np
2 import cv2
3 from matplotlib import pyplot as plt
4 from google.colab import drive
5 from google.colab.patches import cv2_imshow
6 drive.mount('/content/drive')
7 img = cv2.imread("/content/drive/My Drive/Colab Notebooks/image_processing/week3.bmp")
8 print(img.shape)
```

Drive already mounted at /content/drive; to attempt to forcibly remount, call drive.mount("/content/drive", force_remount=True).
(225, 225, 3)

掛載雲端硬碟，並載入我在網路上抓到之 bmp 檔

```
def image_quantization(img, bits):
    nr, nc = img.shape[:2]
    retImg = img.copy()
    levels = 2 ** bits
    interval = 256 / levels
    gray_level_interval = 255 / (levels)
    table = np.zeros(256)

    for k in range(256):
        for l in range(levels):
            if k >= l * interval and k < (l + 1) * interval:
                table[k] = round(l * gray_level_interval)

    for x in range(nr):
        for y in range(nc):
            retImg[x, y] = np.uint8(table[img[x, y]])


    return retImg
```

定義函式 image_quantization

```
1 img_5bit = image_quantization(img, 5)
2 img_2bit = image_quantization(img, 2)
3 images = [img, img_5bit, img_2bit]
4 titles = ['Original', 'QZ 5bits', 'QZ 2bits']
5 plt.figure(figsize = (25, 15))
6
7 for i in range(3):
8     plt.subplot(1, 3, i + 1), plt.imshow(images[i], 'gray')
9     plt.title(titles[i], fontsize = 20, color = 'r')
10
11 plt.tight_layout()
12 plt.show()
```

將數值帶入函式 image_quantization 並顯示結果

結果:



簡答題

Nyquist-Shammon 取樣定理：

取樣定理是讓取樣頻率高於原訊號最高頻率 2 倍以上，來使得取樣之結果不會失真

混疊 (Aliasing) 現象：

若取樣頻率不足時，即會產生混疊現象，易失真